



## Autoject® 2

1. Push the depth adjuster end of the syringe housing assembly inside the injector body until it will go no further.
2. Insert the filled syringe into the syringe housing.
3. Screw the syringe housing and injector body together.
4. Adjust the depth adjuster to the required depth of needle penetration
5. Press the device against the injection site (this releases the safety mechanism) and press the activation button. This will automatically insert the needle and inject the drug. When the yellow plunger appears in the window the injection is complete.