



Autoject[®] Mini

1. Push the injector body down over the plunger until the plunger is retracted into the body and a click is heard.
2. Insert the syringe into the syringe housing and push down firmly.
3. Screw the injector body and syringe housing together.
4. Remove the needle shield of the syringe by pulling on the boot remover.
5. Twist the activation button so that it points to the green circle (this releases the safety mechanism).
6. Place the device against the injection site and press the activation button. This will automatically insert the needle and inject the drug. Count to ten, and then remove the device from the injection site.