

UniAutoject[®]

1. Remove end cap.
2. Press button to inject.
3. After delivery press on the back end of the button to retract needle then safely dispose.



UniAutoject[®]